

TAPCO TAPE INSTRUCTIONS

Step 1: Clamp Tapco Tape onto the anvil of the brake

Step 2: Remove material stops

Step 3: Clean with rubbing alcohol or denatured alcohol

Step 4: Mark center just above angle and at the end of each arm

Step 5: Line up center tick mark on scale sticker with center mark and edge of anvil

Important: Make sure it is lined up with edge of anvil to get accurate measurements.



Step 6: Reinstall material stops

Note: Adjust tension on the arms movement by adjusting the back allen bolt and nut.

Tapco-Europe-Tools.com | +44 (0)1482 880478

Westlake