



# Tapco Tape™

**NEW!** Tapco Tape is an accessory that allows you to measure from your brake anvil and with 1.5" (38mm) offset needed for the Pro-Cutoff without using a tape measure. It clamps quickly to the brake for easy installation. It also has material stops to make repeat bends easy. This accessory will help make bending easier, faster, and more precise.



- Quick installation process.
- Just flips out of the way when using a cut-off tool.
- Simply swing it down for a measuring scale to achieve all bends and cut-off measurements.
- No need to mark material with a tape measure and line up marks with anvil of brake.
- Use the material stops for repeat bends and cuts.
- UV Stabilised and laminated heavy duty sticker will not wear out since it is above the trim coil.
- Does not require drilling holes in your brake to install.
- Nothing to hold onto when using your brake since the Tapco Tape hinges up and out of the way.
- **Two-sided scale:** One side calculates 1-1/2" (38mm) for CutOff and the other side is for the Anvil.
- **Won't fall off:** Pulling on Tapco Tape to keep pressure on material won't cause the accessory to fall off.