


PRO-COILER® INSTALLATION INSTRUCTIONS



Pro-Coiler shown on "Windy" SP, coil not included

The portable coil holder that becomes an integral part of your "Windy" SP Port-O-Brake to increase your production and help eliminate waste.



Lightweight and easy to use.
Weighs less than 10 lbs. Hooks on to your Brake in seconds.



Changes coils quickly. Coil capacity up to 24" wide and 150' long.



Plastic Coil Guards provided. Install as indicated. Protects Coil from marring.



Fast, simple one-man operation.
Roll out and cut squarely to your exact length.



Detaches easily at the end of the day. Keeps your coil factory fresh.

Installation on Port-O-Slitter Stand



PRO-Coiler



Load PRO-Coiler with coil, set into bottom legs of stand as shown in photo. Cut Velcro strap into two pieces.



Wrap the velcro around the PRO-Coiler and Slitter Stand to secure the PRO-Coiler as shown.

Tapco-Europe-Tools.com | +44 (0)1482 880478

Westlake

© 2026 Westlake

TT88150 1/26